

トルク換算表

AVANTIシリーズ

油圧ポンプ 設定圧力	AVANTI-0.7	AVANTI-1	AVANTI-3	AVANTI-5	AVANTI-8	AVANTI-10	AVANTI-20	AVANTI-35	AVANTI-50
BAR	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm
100	134	255	599	998	1,499	2,255	3,598	6,459	9,359
120	164	308	728	1,216	1,825	2,737	4,345	7,800	11,336
140	191	359	850	1,423	2,134	3,195	5,061	9,086	13,223
160	221	414	976	1,634	2,461	3,674	5,826	10,466	15,287
180	249	465	1,096	1,836	2,770	4,133	6,554	11,778	17,225
200	277	517	1,216	2,038	3,079	4,591	7,282	13,088	19,165
220	308	571	1,344	2,250	3,405	5,075	8,037	14,482	21,138
240	336	621	1,466	2,454	3,715	5,538	8,756	15,810	22,991
260	365	671	1,588	2,658	4,024	6,003	9,465	17,148	24,782
280	393	722	1,709	2,862	4,333	6,466	10,184	18,476	26,632
300	424	774	1,835	3,072	4,656	6,942	10,876	19,854	28,426
320	453	825	1,955	3,273	4,965	7,400	11,566	21,171	30,223
340	481	875	2,074	3,473	5,272	7,853	12,224	22,481	31,929
360	511	927	2,201	3,685	5,593	8,322	12,952	23,902	33,743
380	542	974	2,322	3,882	5,893	8,752	13,616	25,284	35,310
400	571	1,023	2,443	4,083	6,198	9,197	14,307	26,640	37,024
420	600	1,073	2,565	4,284	6,504	9,642	14,997	27,997	38,734
440	630	1,124	2,689	4,485	6,815	10,088	15,658	29,394	40,320
460	659	1,173	2,810	4,682	7,118	10,530	16,327	30,727	41,984
480	690	1,224	2,934	4,883	7,430	10,977	16,989	32,123	43,577
500	719	1,274	3,053	5,077	7,729	11,412	17,653	33,432	45,141
520	749	1,320	3,171	5,263	8,016	11,827	18,274	34,716	46,464
540	780	1,369	3,290	5,458	8,314	12,262	18,936	36,026	48,020
560	812	1,419	3,414	5,654	8,617	12,697	19,635	37,433	49,244
580	842	1,468	3,533	5,849	8,912	13,130	20,339	38,799	50,593
600	872	1,517	3,651	6,038	9,198	13,542	21,046	40,195	51,547
620	904	1,568	3,777	6,243	9,510	13,995	21,784	41,630	52,970
640	933	1,617	3,894	6,436	9,803	14,419	22,489	42,941	54,387
660	964	1,666	4,007	6,621	10,085	14,818	23,195	44,221	55,523
680	993	1,717	4,124	6,814	10,379	15,243	23,899	45,531	56,933
690	1,009	1,741	4,181	6,907	10,519	15,442	24,252	46,172	57,505