

## トルク換算表

## ICEシリーズ

油圧ポンプ 設定圧力	1ICE	3ICE	5ICE
BAR	Nm	Nm	Nm
100	256	599	1,048
120	309	728	1,266
140	359	850	1,474
160	413	976	1,691
180	466	1,096	1,900
200	517	1,216	2,106
220	571	1,344	2,325
240	622	1,466	2,533
260	671	1,588	2,740
280	722	1,709	2,948
300	774	1,835	3,165
320	825	1,955	3,374
340	875	2,074	3,580
360	927	2,201	3,799
380	975	2,322	4,006
400	1,023	2,443	4,214
420	1,072	2,565	4,423
440	1,123	2,689	4,639
460	1,174	2,810	4,849
480	1,225	2,934	5,065
500	1,273	3,053	5,274
520	1,320	3,171	5,480
540	1,369	3,290	5,688
560	1,419	3,414	5,905
580	1,469	3,533	6,114
600	1,516	3,651	6,320
620	1,568	3,777	6,539
640	1,618	3,895	6,748
660	1,667	4,007	6,954
680	1,716	4,124	7,163
690	1,741	4,180	7,266